

English (英語)

Getting Started

Note: The Setup program of the PCR-L Applications decompresses and copies the application programs to your hard disk. Before you start using the applications, you must use the Setup program. Therefore, you cannot copy the files manually.

System Requirements

To use PCR-L Applications, your computer must meet the following requirements:

- A personal computer with a 386/33 or faster microprocessor, with a hard disk drive and a high-density floppy drive.
- 2MB or more extended memory.
- 3MB or more free disk space.
- VGA-color or better video subsystem.
- Microsoft Windows 3.1/Windows 95 and a mouse.
- A National Instruments GPIB board installed (if you use GPIB).
- Kikusui IB11-PCR-L GPIB Interface (if you use GPIB).
- Kikusui RS11-PCR-L RS232-C Interface (if you use RS232-C).

Some programs also require additional equipment and faster PC for the best performance.

Linzo:(SD02-PCR-L only)

- Kikusui LIN40M-PCR-L — the Line Impedance Network
- Graphics printer that is compatible with Windows 3.1/Windows 95
- PCR-L's Rom version 2.04 or higher

Harmonics Synthesizer:

- PCR-L's Rom version 2.03 or higher

Easy Power Waveformer:

- A digital storage scope connected to GPIB or RS232 (See chapter 2 "Easy Power Waveformer" on the user's manual for more information.)

Supported GPIB cards

The following list shows the National Instruments NI-488.2/2M GPIB adapter cards that are available on the applications. You can select one of these models corresponding to your PC expansion bus.

- GPIB-PC2/2A (Windows 3.1 only)
- MC-GPIB (Windows 3.1 only)
- AT-GPIB/TNT
- PCMCIA-GPIB

Setup

To set up the PCR-L Applications package to your hard disk, insert the master diskette on the drive A and then select **File Run** from Program Manager (Windows 3.1) or **Start Run** from TaskBar (Windows 95). Then type

A : SETUP

and click the OK button. If your diskette drive is other than A, you may replace the drive letter with a proper name. After the setup screen appears, follow the setup instruction.

"This product is subject to the Foreign Exchange & Foreign Trade Control Laws of Japan and the export procedure stipulated by the laws must be executed in case of export from Japan."

KIKUSUI ELECTRONICS CORP.

1-1-3, Higashiyamata, Tsuzuki-ku, Yokohama, 224-0023, Japan

Tel : 045-593-7570 Fax : 045-593-7571